

CHEMICAL FLOODING (Micellar-Polymer)

The method shown requires a preflush to condition the reservoir, the injection of a micellar fluid for releasing oil, followed by a polymer solution for mobility control to minimize channeling, and a driving fluid (water) to move the chemicals and resulting oil bank to production wells.

(Single 5-Spot Pattern Shown)

